



Review: National Laboratory Sensor Projects for CIDI/SIDI Engines

DOE Workshop on Sensors for Fuel Cells and CIDI/SIDI Engines

January 25, 2000

Richard W. Cernosek
Sandia National Laboratories
Albuquerque, NM



Sandia is a multiprogram laboratory operated by Sandia Corporation, a Lockheed Martin Company,
for the United States Department of Energy under contract DE-AC04-94AL85000.





Presentation Outline

- Vehicle exhaust gas constituent sensors being developed under DOE CRADA 94-MULT-912-ES (LANL, LLNL, ANL, and SNL with USCAR/LEP)
- Other gas sensor technology development at the National Labs
 - NO_x, CO, HCs, O₂, H₂
- Other sensor developments for engine systems
 - Particulate counters
 - Pressure monitors
 - Fuel vapor sensors
 - Fluid monitors
 - Rotation/position sensors





LANL Sensor Development

Fernando Garzon- Project Leader, Eric Brosha, R. Mukundan and
David Brown -Technical Staff

- Goal - develop with USCAR new ceramic sensors that measure hydrocarbons/carbon monoxide directly
- Electrochemical ceramic sensors capable of *insitu* operation (temperatures from 400-900 C)
- All new autos use ceramic zirconia sensors -proven technology
- Good sensitivity and fast response
- Simple transduction voltage or current electrical signal
- Ease of sensor fabrication and detector system implementation "spark plug" type device
- Fast light off -micro-sensors can be self-heated



LANL Sensor Development Cont.

- A non-equilibrium potential develops at an electrode in the presence of reducing-gases
- Detect reducing-gases (H_2 , CO , hydrocarbons, NO_x) in an oxygen containing stream
- Mixed Potential is fixed when the rates of the reduction and oxidation reactions are equal
- The Mixed Potential is different on dissimilar catalytic electrodes
- Potential difference between electrodes A and B is sensor response




LANL Sensor Development Cont.

- LANL sensors show fast reproducible responses to hydrocarbons such as propylene
- Long term stability and durability- over 3000 hours of laboratory testing under simulated exhaust gas mixtures
- Ongoing engine testing with USCAR for use as OBD II sensors
- Patent applied for sensor technology



3 electrode device mounted onto a ceramic tube with a glass seal

At Lawrence Livermore National Lab, we are developing solid state electrochemical sensors for HC emissions monitoring



Principle of operation: this is a catalytic versus non-catalytic sensing mechanism. Various catalysts can be used to decompose HCs to hydrogen. The excess hydrogen concentration is detected by the hydrogen sensor.

Advantages:


- simple
- robust
- low cost
- can be very selective

Ai-Quoc Pham, (925)423-3394, pham2@llnl.gov
Robert S. Glass, (925)423-7140, glass3@llnl.gov

Characteristics of LLNL HC sensor




Sensor response to C_2H_6




- sensor responds to various HCs in both lean and rich conditions
- no drifting
- response time is less than 5 s
- absolute selectivity versus H_2 and CO
- no flow rate dependence
- weak temperature dependence
- some oxygen dependence



Sensor response to CO



The first generation sensor has been submitted to dynamometer test at Ford Research Lab



Exhaust HC Ion Mobility Sensor



Description:

- Miniaturized intelligent ion mobility sensor array incorporates chemically selective membranes.
- Multiple chemically selective membrane inlet system provides enhanced specificity over conventional IM system.
- Capable of analyzing samples from semivolatiles, and volatiles without preparation with high sensitivities.

Applications:

- Land Mine detection
- Explosive detection
- Troop security
- Clandestine or covert operations
- Cooperative treaty monitoring
- Law enforcement support
- Chemical weapons detection
- Detection of nuclear proliferation activities/facilities

ARGONNE








- ARGONNE**



SNL Acoustic Wave HC Gas Sensor



- Sensor consists of AT-cut quartz TSM resonator with catalytic-metal-doped porous silica thin film on surface.
- CTAB surfactant in sol-gel templates pores and achieves high surface area ($> 700 \text{ m}^2/\text{g}$). Pd doping elicits strong HC response.
- Catalytic combustion of HCs + O_2 in film increases the temperature, stressing resonator surface, and shifting frequency. Response is similar to a calorimeter.
- Operation to $\sim 525^\circ\text{C}$. Quartz Curie point 573°C .
- Min. detection limits $< 50 \text{ ppm } [\text{C}_3\text{H}_6]$
Response time: few seconds
 O_2 dependent response at high conc.
No cross-sensitivity to CO or NO_x
Small sensitivity to CO_2 and H_2O
- Prototype system being prepared for performance evaluation





PI: Richard W. Cernosek, (505)845-8818, rwcerano@sandia.gov





ORNL NOx Sensor



Sensor Type #1 (Gasoline lean burn engine)

Sensitivity: 100-200 ppm (potential lower detection limit for diagnostics)

Accuracy: +/- 20 ppm

Response Time: < 1 sec (0-90% full scale)

NO/NO₂: equally sensitive to NO and NO₂

Concerns: sulphur

Sensor Type #2 (Diesel application with urea)


Sensitivity: 20-300 ppm

Accuracy: +/- 20ppm

Response Time: < 1sec (0-90% full scale)

NO/NO₂: separately measure NO and NO₂

Concerns: soot, sulphur and urea(NH₃)



Contact:

Tim Armstrong

Oak Ridge National Laboratory

(423) 574-7996

armstrongt@ornl.gov



Accomplishments in PNNL Oxygen and NOx Sensor Development Programs



Development of:


- Aqueous tape casting system
- High electrical resistance barrier layer
- Porous protective layer
- Gas diffusion layer
- Novel selective electrode materials

Five year history of materials development, testing and evaluation with OEM and suppliers


PNNL Sensor Capabilities

- Novel materials design and synthesis
- Materials processing (tape casting, tape calendering,...)
- Material Analysis and Characterization
 - Surface (XPS, Auger, SEM, FTIR, Raman)
 - Bulk (XRD, TEM, NMR)
- Sensor testing & evaluation
 - Gas phase (pure gases, simulated exhaust, real exhaust) using FTIR, GC/MS
 - Electrical properties

SNL Micromachined Catalytic Gas Sensor




- Suspended polysilicon filaments 2 μm thick, 10 μm wide, and 100 to 1000 μm long
- Micro-CVD deposition of catalytic Pt coating
- Combustible gases (CO , H_2 , HCs) react with O_2 on filament, releasing heat
- Constant resistance (temperature) control circuit allows gas concentration to be determined from measured power
- Small suspended filaments allow for efficient electrical heating and isolation
- Dual bridge provides for self-compensating design
- Micromachining allows for batch processing and microelectronic integration
- Applications: natural gas BTU monitor, catalytic converter monitor



Lean-Burn Oxygen Sensors

- Zirconia oxygen sensors work well around stoichiometric (air-fuel ratio: 14.8 to 1). Potentiometric response is non-linear (λ shape) with changes in O_2 partial pressure.
- Lean-burn engines require wider dynamic range of O_2 concentrations. Air-fuel ratios > 15
- LANL and LLNL development of linear amperometric O_2 sensors with porous metal oxide or pin-hole aperture diffusion barriers.
- Linear response up to 25% O_2 partial pressure.




LANL linear
response
oxygen sensor




Hydrogen Detectors

- Solid-state catalytic gate (Pd-Ni) FETs [SNL]
- Thin-film Pd-Ni chemical resistor on silicon [SNL]
- Thick-film Pd chemical resistor on ceramic [ORNL]
- Optical fiber with chemochromic thin films [NREL]
- Optical fiber with Pd thin film [SNL]


Sandia's robust
integrated
hydrogen sensor



Diesel Particle Scatterometer (DPS)




- Particulates from newer engines are smaller and more difficult to measure.
- Polarized light scattering provides rapid, accurate, and *in situ* measurement of diesel exhaust particulate characteristics:
 - size, number density, morphology, and optical properties
- DPS used to study variables: engine type, load, RPM, fuel additives, and post-combustion processes




- Simultaneous measurements on Jetta Diesel engine at ORNL using the DPS, and the Scanning Mobility Particle Analyzer (SMPS) - Standard method, but slow
- Demonstrated DPS operation at > 1 Hz data rates

Arlon J. Hunt, ajhunt@lbl.gov
Env. Energy Tech. Div.



Ultrasonic Particulate Monitor



Description:

The ANL ultrasonic particulate analyzer detects particles/smoke in air by measuring changes in sound velocity and acoustic attenuation. It consists of an acoustic cavity and a pair of piezoelectric transducers operated in a pitch-catch mode.

Instrument features:

- Rugged
- Low cost
- Easy operation

Other Applications:


- Helium/hydrogen leak detectors
- Radon gas detector
- Trace toxic gas detector

ARGONNE







Ultrasonic Sensor for Cylinder Pressure Monitoring



Pressure Sensors



- MEMS pressure sensors [SNL]
- Devices fabricated using bulk (poly-Si) or surface (SiN) micromachining
- Sensing with poly-Si piezoresistors



- Optical fiber pressure sensor using micromachined Si membrane [LLNL]
- Fabry-Perot cavity formed by glass plate and deflecting membrane
- Uses LED light source
- Dynamic range to > 1000 psi






Fuel Composition Monitors

- Chemical sensor arrays detect fuel vapors.
 - Coated acoustic devices or resonant structures: SAWs, QCMs (TSM resonators), FPWs, microcantilevers [SNL, ANL, PNNL, ORNL]
 - Chemiresistors [LLNL, ORNL, PNNL, SNL]
 - ChemFETs [PNNL, SNL]
- Diverse sensor coatings are partially selective to many vapor molecules.
- Pattern recognition algorithms, neural networks, or other chemometric techniques used to identify and quantify vapors.





SNL Oil Viscosity Monitor



- A thickness shear mode quartz crystal resonator viscously-entrains liquid in contact with the surface
- Shifts in resonant frequency and magnitude are proportional to liquid density-viscosity

- Extracted oil samples can be placed on resonator surface
- Robustly packaged resonators can be mounted in vehicle oil pan or placed in oil flow line
- Tests conducted in laboratory, in engine dynamometers, and in operating vehicles



- Lubricant viscosity increases as oil degrades (oxidation due to high temperatures and pressures)
- Resonator response agrees well with viscosity measured using ASTM techniques (correlation > 0.9)



PI: Richard W. Cernosek, (505)845-8818, rwcerno@sandia.gov






Rotation/Position Sensors

- Non-contact rotation and position sensors measure the crankshaft angle, engine rotation speed, and other shaft positions.
- Desire wide linear dynamic range, high resolution ($\sim 0.1\%$), low cost, and long life at high temperatures.
- Planar Hall effect devices [SNL]
 - InSb and InAlSb (high m_e) on GaAs substrates
- Giant Magnetoresistance (GMR) field sensors [ORNL]
 - Alternating layers of ferromagnetic and nonmagnetic material
- Rotary differential capacitance transducers [ORNL]
 - Shaped electrodes with 25 μm polyester film dielectric



Total Engine and Exhaust Emission Monitoring



ARGONNE

